

FLINT IGNITOR 38-0309-00

The 38-0309-00 Flint Ignitor is used to ignite the starting powder. Each mold that is sold with a frame has a Flint Ignitor included.

Replacement flints are available upon request.

Part #38-0309-01.



FLINT IGNITOR EXTENSION 38-0904-00

The 38-0904-00 Flint Ignitor Extension allows the installer to stand 36" from the mold. Flint Ignitor is included.



ELECTRONIC FLINT TRIGGER 38-8253-00

thermOweld's new Electronic Flint Trigger is designed to ignite the starting powder by generating time delayed sparks of 5, 10 or 15 seconds, igniting the starting powder on top on the mold. The Trigger mount to the side of the any size mold with a magnet.

